

HOW TO SPRAY LIQUIDSHIELD™ CERAMIC SPRAY WAX

BEFORE GETTING STARTED

Make sure you aren't spraying in high humidity, direct sunlight, rain, wind or any source of contaminants. Do not apply the product on hot surfaces. Don't forget to scan the QR code below for complete instructions and videos.

ONLY APPLY ON

Painted body panels, headlights, windshields, wheels and carbon fiber surfaces.

STEP

1 PREPARATION

USE LiquidShield Prep Wipes | Microfiber Cloth

Thoroughly wash and rinse the surface to remove loose dirt and debris.
Use the LiquidShield Prep Wipe to remove any surface oils, contaminants or residue.
Dry the surface using a clean microfiber cloth.

STEP

2 APPLICATION

USE Ceramic Spray Wax | Microfiber Cloth

Working one panel at a time, spray a thin and even coat on the surface.
Wait 1-2 minutes and buff the surface using a clean microfiber cloth.
Allow 4 hours to cure before exposing your surface to elements (sun, rain, etc.)



FIRST TIME?
SCAN HERE FOR IN-DEPTH
VIDEO INSTRUCTIONS

MORE QUESTIONS?
CONTACT OUR TEAM AT
INFO@GETLIQUIDSHIELD.COM



LIQUIDSHIELDOFFICIAL

LIQUIDSHIELDOFFICIAL

GETLIQUIDSHIELD

