

HOW TO APPLY **LIQUIDSHIELD™** SPRAY CERAMIC COATING

BEFORE GETTING STARTED

Make sure you are spraying indoors in a well-ventilated area protected from the sun, rain and any source of contaminants. Spray in temperatures between 60-75 °F and with a humidity-level below 60%. Do not apply the product on hot surfaces. Wear protective gloves while using the product. Don't forget to scan the QR code below for complete instructions and videos.

ONLY APPLY ON

Undamaged painted body panels. Wheels that are OEM clearcoated or alloy. Do not apply if your surface has rust, severe scratches, or fading/cracking.

STEP

1 PREPARATION

USE LiquidShield Isopropyl Prep Wipes | Microfiber Cloth

Thoroughly wash and rinse the surface to remove loose dirt and debris.

Use the LiquidShield Prep Wipe to remove any surface oils, contaminants or residue.

Dry the surface using a clean microfiber cloth.

STEP

2 APPLICATION

USE Spray Ceramic Coating | Microfiber Cloth

Working one panel at a time, spray a thin and even coat on a cool, clean and dry surface.

Wait 1-2 minutes and buff the surface using a microfiber cloth.

For best results, after the application, allow 1-2 hours to cure before exposing your surface to elements (sun, rain, etc.)



FIRST TIME?
SCAN HERE FOR IN-DEPTH
VIDEO INSTRUCTIONS

MORE QUESTIONS?
CONTACT OUR TEAM AT
INFO@GETLIQUIDSHIELD.COM



LIQUIDSHIELDOFFICIAL

LIQUIDSHIELDOFFICIAL

GETLIQUIDSHIELD

