

# HEADLIGHT PROTECTION

## HOW TO SPRAY

### COVERAGE CHART

Small Headlights (2): 2x Aerosols

Large Headlights (2): 3x Aerosols

### BEFORE GETTING STARTED MAKE SURE THAT

You aren't spraying in high humidity, direct sunlight or windy conditions. Only use in temperatures between 68-82°F with humidity level below 60%.

**ALSO**

Only apply LiquidShield Headlight Protection on automotive/motorcycle headlights. We do not recommend applying LiquidShield on plastics, stickers, rubber, laminated centercaps. Please allow the surface to fully cure (5+ days) before exposing them to the rain or washing them.

STEP

## 1 PREPARATION

USE Prep Spray | Microfiber cloth

Thoroughly wash and rinse the surface to remove loose dirt and debris. Use Superwrap Prep Spray. Let the product sit for no more than one (1) minute. Wipe surface dry with a clean microfiber cloth.

\* Avoid using household soaps to wash the surface.

\* If your headlights are damaged and the finishing clearcoat has been affected, do not apply LiquidShield.

STEP

## 2 MASKING

USE Masking tape | Tape & Drape

Use 3M Auto Performance Masking Tape. Extensively mask off surrounding areas. Use a plastic card to tuck the tape into the gap.

\* We recommend putting the aerosols in hot water for 10 minutes before spraying.

STEP

## 3 SPRAYING

USE LiquidShield Headlight Aerosol

Apply one light first coat. Allow a 15 minute drying period between coats. Apply 10 wet coats of LiquidShield Headlight.

\* Use all cans provided in the kit.

STEP

## 4 UNMASKING

USE Card | Blade

Wait at least 1h for the final coat to dry and use a card or blade to crease the tape. Pulling away from the surface, remove masking tape.



Want more tips? Check out our complete instructions, trips and tricks [GETSUPERWRAP.COM/HOW-TO-SPRAY](https://www.getsuperwrap.com/how-to-spray) Still have questions? Contact our support team at [info@getsuperwrap.com](mailto:info@getsuperwrap.com)

 **SUPERWRAPOFFICIAL**  
 **SUPERWRAPOFFICIAL**  
 **GETSUPERWRAP**

